

F-16 AIRCRAFT

Repair and Overhaul

U.S. Dynamics Corporation provides a wide range of services to extend the life of Avionics and Military Electronics.

Systems Supported:

- AN-APG-66
- AN-APG-68
- Rate and Rate Integrating Gyroscopes



SERVICES INCLUDE

- Repair
- Overhaul
- Spares
- Technology Insertion
- Reverse Engineering
- DMSMS support




Environmental Test Facility

- Altitude
- Temperature
- Shock & Vibration
- Humidity
- Acceleration



F-16 AIRCRAFT

Repair and Overhaul



Gyroscope Assembly and Manufacturing Area
Providing Replacement Gyroscopes for Northrop, Honeywell, Condor, BAE, AIS, Rosemount and Goodrich.

[Click here to submit an RFQ or to request more information.](#)

OEM P/N	USD P/N	FSC	NIIN	DESCRIPTION	SYSTEM	REPAIR	NEW BUILD
484674		5998	01-071-4905	CIRCUIT CARD ASSEMBLY		✓	✓
2113245		6130	01-084-8523	POWER SUPPLY		✓	
3129307		6130	01-388-0266	POWER SUPPLY		✓	
1003050G-5		5998	01-447-3845	CIRCUIT CARD ASSEMBLY		✓	
1003098G3		5998	01-410-7407	PC BOARD		✓	
11217-2		1660	01-196-5999	ECS SENSOR CONTROLLER		✓	
11221-1		1660	01-134-3021	ELECTRICAL CONTROL BOX		✓	
11221-4		1660	01-134-3021	ELECTRICAL CONTROL BOX		✓	
11221-7		1660	01-236-1136	ELECTRICAL CONTROL BOX		✓	
16C0610-821		5998	01-462-4550	CIRCUIT CARD ASSEMBLY		✓	
16C0858-801		5998	01-090-2639	AIR DATA COMPUTATION, CCA		✓	
16E10016-829		5998	01-439-0670	CIRCUIT CARD ASSEMBLY		✓	
16E2504-869		6110	01-440-4999	POWER DISTRIBUTOR PANEL		✓	
16E2505-839		6110	01-440-4997	POWER DISTRIBUTOR PANEL		✓	
16E2545-145		6110	01-265-1080	POWER DISTRIBUTION PANEL		✓	
16E3641	583570 583570	1680	01-518-9074	POWER CONTROL ASSEMBLY			✓
16E3641-857	583570	1680	01-518-9074	POWER CONTROL ASSEMBLY			✓
16L401-811		1680	01-399-7495	LANDING GEAR CONTROL ASSEMBLY		✓	
16U184-811		5998	01-122-6996	CIRCUIT CARD ASSEMBLY		✓	
16U446-1		5998	01-072-6244	CIRCUIT CARD ASSEMBLY			✓
16U446-805		5998	01-072-6244	CIRCUIT CARD ASSEMBLY			✓
16VE584025-4		6130	01-388-0266	POWER SUPPLY		✓	
16VY010002-2		1660	01-196-5999	ECS SENSOR CONTROLLER		✓	
16VY12001-4		1660	01-134-3021	ELECTRICAL CONTROL BOX		✓	
2113245-103		6130	01-084-8523	POWER SUPPLY		✓	
2113245-123		6130	01-084-8523	POWER SUPPLY		✓	
2115060-101		5998	01-079-2200	CIRCUIT CARD ASSEMBLY		✓	
2115060-102		5998	01-079-2200	CIRCUIT CARD ASSEMBLY		✓	
2115475-201		5998	01-266-7051	CIRCUIT CARD ASSEMBLY		✓	
2115475-202		5998	01-266-7051	CIRCUIT CARD ASSEMBLY		✓	
2215190-001		5998	01-372-6652	CIRCUIT CARD ASSEMBLY		✓	
2215190-002		5998	01-372-6652	CIRCUIT CARD ASSEMBLY		✓	
229-026256-05		5998	99-533-9125	CIRCUIT CARD ASSEMBLY		✓	
229-026256-11		5998	99-533-9125	CIRCUIT CARD ASSEMBLY		✓	
229-026256-12		5998	99-533-9125	CIRCUIT CARD ASSEMBLY		✓	
229-026257-03		6130	99-736-0409	POWER SUPPLY SUBASSEMBLY		✓	
229-026259-05		5998	99-771-4188	DEFLECTION PCB		✓	
29650-19A		6130	01-086-2340	POWER SUPPLY		✓	
3129307-1		6130	01-388-0266	POWER SUPPLY		✓	
3129307-4		6130	01-388-0266	POWER SUPPLY		✓	
460730-05-06		5998	01-430-2593	CIRCUIT CARD ASSEMBLY		✓	
536R477G01	588410	1270	01-132-2438	DETECTOR ASSEMBLY			✓
681R622G01		1270	01-102-2965	RADAR RECEIVER- GENERATOR		✓	
688R012G01		5998	01-107-0140	CIRCUIT CARD ASSEMBLY		✓	
754R778G01		5998	01-193-8150	CIRCUIT CARD ASSEMBLY		✓	
762R592G01		5998	01-356-4897	TRANSMITTER DIGIBUSCCA		✓	
785R537G01	585000	5998	01-303-5871	RF MONITORCCA			✓
8001023-922		1260	01-220-4070	CIRCUIT CARD ASSEMBLY		✓	
8001294-921		5998	01-193-8900	ELECTRONIC COMPONENTS ASSEMBLY		✓	
8002287-930		6130	01-234-8700	POWER SUPPLY		✓	
D2817-A103		6130	01-084-8523	POWER SUPPLY		✓	
D2817-A123		6130	01-084-8523	POWER SUPPLY		✓	

OEM P/N	USD P/N	FSC	NIIN	DESCRIPTION	SYSTEM	REPAIR	NEW BUILD
16E1039-667		6130	01-153-0481	BATTERY-CHASIS CONTROL ASSEMBLY		✓	
16E1039-683		6130	01-153-0481	BATTERY-CHASIS CONTROL ASSEMBLY		✓	
16E1039-687		6130	01-206-7808	BATTERY-CHASIS CONTROL ASSEMBLY		✓	
16E1132-837		1680	01-135-4597	LANDING GEAR CONTROL PANEL ASSEMBLY		✓	
16E1208-5		5998	01-120-2059	STORES CONTROL PANEL COMMON POWER DRIVER CCA		✓	
947F310-1		6110	01-038-5065	GENERATOR CONTROL UNIT		✓	
2115400-101	585240	5998	01-078-0500	STRAY VOLTAGE CIRCUIT BOARD ASSEMBLY	AEROSPACE GROUND EQUIPMENT (AGE)	✓	✓
2115400-103	585240	5998	01-078-0500	STRAY VOLTAGE CIRCUIT BOARD ASSEMBLY	AEROSPACE GROUND EQUIPMENT (AGE)	✓	✓
2113024-114		4920	01-108-1292	DISK DRIVE	AIS TEST STATION	✓	
2115080-101		5998	01-077-1445	DC REFERENCE AND RESISTANCE CCA	AIS TEST STATION	✓	
2115080-102		5998	01-077-1445	DC REFERENCE AND RESISTANCE CCA	AIS TEST STATION	✓	
2115080-303		5998	01-077-1445	DC REFERENCE AND RESISTANCE CCA	AIS TEST STATION	✓	
2115530-101		5998	01-078-1833	SPECIAL EQUIPMENT CONTROLLER CCA	AIS TEST STATION	✓	
578R611H01	585155	5865	00-007-6950	DRIVE CONTROL	AN/ALQ-119, 184	✓	✓
578R611H04	585155	5865	00-007-6950	DRIVE CONTROL	AN/ALQ-119, 184	✓	✓
MPS162A	585155	5865	00-007-6950	DRIVE CONTROL	AN/ALQ-119, 184	✓	✓
109700-1		6130	01-356-3740	HVPS	AN/ALQ-184	✓	
452-575-2		*	*	HIGH VOLTAGE TRANSFORMER & DIODE TRAY MODULE	AN/ALQ-184	✓	
452-582-1		*	*	DIODE TRAY ASSEMBLY	AN/ALQ-184	✓	
452-700-3		6130	01-183-3927	HVPS	AN/ALQ-184	✓	
G254084-1		6130	01-183-3927	HVPS	AN/ALQ-184	✓	
G254084-1V1		6130	01-183-3927	HVPS	AN/ALQ-184	✓	
G254084-1V2		6130	01-356-3740	HVPS	AN/ALQ-184	✓	
G254084-1V3		6130	01-411-4286	HVPS	AN/ALQ-184	✓	
G385200-1		6130	01-411-4286	HVPS	AN/ALQ-184	✓	
G385920-3U2	580215	5996	01-337-3516	RF AMPLIFIER	AN/ALQ-184		✓
G385920-4	580230	5996	01-338-0555	RADIO FREQUENCY AMPLIFIER	AN/ALQ-184		✓
PS101167		6130	01-183-3927	HVPS	AN/ALQ-184	✓	
1615		5999	01-282-6680	ELECTRONIC COMPONENTS ASSEMBLY	AN/ALR-56		✓
308036-750		5999	01-282-6680	ELECTRONIC COMPONENTS ASSEMBLY	AN/ALR-56		✓
11352		6130	01-082-7817	POWER SUPPLY/ ION PUMP	AN/APG-66		✓
60642		6130	01-082-7817	POWER SUPPLY/ ION PUMP	AN/APG-66		✓
0800318	544022	5841	01-101-3619	RADAR MODULATOR	AN/APG-66		✓
362D37H01		5985	01-030-9462	DIPLEXER	AN/APG-66	✓	✓
583R290H01	585140	1270	01-077-0718	MICROWAVE GUNN EFFECT FIXED OSCILLATOR	AN/APG-66	✓	✓
583R290H02	585140	1270	01-077-0718	MICROWAVE GUNN EFFECT FIXED OSCILLATOR	AN/APG-66	✓	✓
583R936H01		1270	01-096-7120	FREQUENCY MULTIPLIER	AN/APG-66	✓	
583R936H02		1270	01-096-7120	FREQUENCY MULTIPLIER	AN/APG-66	✓	
583R936H03		1270	01-222-3541	FREQUENCY MULTIPLIER	AN/APG-66	✓	
583R936H04		1270	01-096-7120	FREQUENCY MULTIPLIER	AN/APG-66	✓	
583R936H05		1270	01-343-8506	FREQUENCY MULTIPLIER	AN/APG-66	✓	
583R936H06		*	*	FREQUENCY MULTIPLIER	AN/APG-66	✓	

OEM P/N	USD P/N	FSC	NIIN	DESCRIPTION	SYSTEM	REPAIR	NEW BUILD
584R453H01	585130	6130	01-082-7817	POWER SUPPLY/ ION PUMP	AN/APG-66		✓
646R666G01	585120	1270	01-083-5926	GROUND DECK PULSER	AN/APG-66	✓	✓
646R861G01	585190	1270	01-077-0710	RECEIVER ASSEMBLY	AN/APG-66	✓	✓
681R267G01		6130	01-080-1216	POWER SUPPLY - DIGITAL SIGNAL PROCESSOR	AN/APG-66	✓	
681R317G03		1270	01-075-9674	REFERENCE SOURCE ASSY	AN/APG-66	✓	
681R326G01		1270	01-089-7286	TRANSMITTER PEAK POWER DETECTOR	AN/APG-66	✓	
681R366G01	585440	1270	01-083-0398	PRESSURE VESSEL ASSEMBLY	AN/APG-66	✓	✓
681R621G01		5998	01-099-3253	ELECTRONIC COMPONENTS ASSEMBY	AN/APG-66	✓	
682R668G01		1270	01-097-6096	PEAK POWER DETECTOR	AN/APG-66	✓	✓
682R717G01		5998	01-101-5290	CIRCUIT CARD ASSEMBLY	AN/APG-66	✓	
682R727G01	585100	1270	01-099-3206	LOW NOISE ASSEMBLY	AN/APG-66		✓
682R975G01		6130	01-103-4551	POWER SUPPLY - RADAR COMPUTER	AN/APG-66	✓	
688R007G01	585135	5998	01-115-3249	PROTECTION CB, CCA	AN/APG-66		✓
70028-02		6130	01-082-7817	POWER SUPPLY/ ION PUMP	AN/APG-66		✓
780R823		5985	01-410-9914	ANTENNA	AN/APG-66	✓	
780R823G01		5985	01-410-9914	ANTENNA	AN/APG-66	✓	
781R129G01		5841	01-398-7211	RADAR TRANSMITTER	AN/APG-66	✓	
781R130		1270	01-410-9915	GENERATOR RECEIVER	AN/APG-66	✓	
781R130		1270	01-416-0083	GENERATOR RECEIVER	AN/APG-66	✓	
781R130		1270	01-416-0085	GENERATOR RECEIVER	AN/APG-66	✓	
781R130		1270	01-416-0086	GENERATOR RECEIVER	AN/APG-66	✓	
781R130G01		1270	01-410-9915	GENERATOR RECEIVER	AN/APG-66	✓	
781R130G02		1270	01-416-0083	GENERATOR RECEIVER	AN/APG-66	✓	
781R130G03		1270	01-416-0086	GENERATOR RECEIVER	AN/APG-66	✓	
781R130G04		1270	01-416-0085	GENERATOR RECEIVER	AN/APG-66	✓	
783R199G01		5955	01-431-8686	NON-CRYSTAL OSCILLATOR	AN/APG-66		✓
783R209G01		5841	01-416-5187	RECEIVER ASSEMBLY	AN/APG-66	✓	
851836-2		6130	01-082-7817	POWER SUPPLY/ ION PUMP	AN/APG-66		✓
C12413-1		1270	01-083-5926	GROUND DECK PULSER	AN/APG-66		✓
FS-2370-1	585140	1270	01-077-0718	MICROWAVE GUNN EFFECT FIXED OSCILLATOR	AN/APG-66	✓	✓
FS-9082		1270	01-222-3541	FREQUENCY MULTIPLIER	AN/APG-66	✓	
M02X222B		1270	01-096-7120	FREQUENCY MULTIPLIER	AN/APG-66	✓	
586R212H06		5841	01-353-9263	TRANSMIT MICROWAVE ASSEMBLY	AN/APG-66, 68	✓	
1761	585025	5996	01-468-8650	LOW NOISE AMPLIFIER	AN/APG-68	✓	✓
7220		5841	01-291-6174	TRANSMIT MICROWAVE ASSEMBLY	AN/APG-68	✓	
7276	585025	5996	01-464-4836	LOW NOISE AMPLIFIER	AN/APG-68	✓	✓
101597		6625	01-124-0226	FREQUENCY MULTIPLIER	AN/APG-68	✓	
5187206		5998	01-497-3309	CIRCUIT CARD ASSEMBLY	AN/APG-68	✓	
12604334		6625	01-124-0226	FREQUENCY MULTIPLIER	AN/APG-68	✓	
01-01375-002		5985	01-294-9788	ANTENNA CONTROL	AN/APG-68	✓	
01-01375-002A		5985	01-294-9788	ANTENNA CONTROL	AN/APG-68	✓	
01-01375-003		5985	01-352-9699	ANTENNA CONTROL	AN/APG-68	✓	
12604334-1		6625	01-124-0226	FREQUENCY MULTIPLIER	AN/APG-68	✓	
12604334-2		6625	01-124-0226	FREQUENCY MULTIPLIER	AN/APG-68	✓	
12604334-3		6625	01-124-0226	FREQUENCY MULTIPLIER	AN/APG-68	✓	
12604334-4		6625	01-124-0226	FREQUENCY MULTIPLIER	AN/APG-68	✓	
16VZ001-17		1270	01-418-1960	GENERATOR, RADIO FREQUENCY	AN/APG-68	✓	
229-029552-01		5820	99-783-4026	CHASSIS	AN/APG-68	✓	
2825131-3		5998	01-384-9455	CIRCUIT CARD ASSEMBLY	AN/APG-68	✓	
560R586H01	585025	5996	01-464-4836	LOW NOISE AMPLIFIER	AN/APG-68	✓	✓

OEM P/N	USD P/N	FSC	NIIN	DESCRIPTION	SYSTEM	REPAIR	NEW BUILD
581R848H58	585090-2	5935	01-155-1165	CONNECTOR, MALE PLUG (160 PIN)	AN/APG-68		✓
585R600H05	585025	5996	01-153-8700	LOW NOISE AMPLIFIER	AN/APG-68	✓	✓
585R600H05	585025	5996	01-464-4836	LOW NOISE AMPLIFIER	AN/APG-68	✓	✓
586R212		5841	01-203-4624	TRANSMIT ASSEMBLY	AN/APG-68	✓	
586R212		5841	01-353-9263	TRANSMIT ASSEMBLY	AN/APG-68	✓	
586R212H03		5841	01-203-4624	TRANSMIT ASSEMBLY	AN/APG-68	✓	
586R212H05		5841	01-291-6174	TRANSMIT ASSEMBLY	AN/APG-68	✓	
586R212H07		5841	01-438-9423	TRANSMIT ASSEMBLY	AN/APG-68	✓	
586R719H01		1270	01-173-4932	TRANSMIT MICROWAVE	AN/APG-68	✓	
586R719H02		1270	01-173-4932	TRANSMIT MICROWAVE	AN/APG-68	✓	
586R719H04		*	*	TRANSMIT MICROWAVE ASSEMBLY	AN/APG-68	✓	
588R881H01		6130	01-439-0638	MLOW POWER RF LOW VOLTAGE POWER SUPPLY	AN/APG-68	✓	
622-8084-001		5985	01-228-9402	AMPLIFIER-CONVERTER	AN/APG-68	✓	
685R059G01		6625	01-124-0226	MICROWAVE FREQUENCY MULTIPLIER	AN/APG-68	✓	
688R683G01	585050	1270	01-132-2440	PHASE SHIFT DRIVER	AN/APG-68	✓	✓
691R748G01	588000	1270	01-132-6867	LOW NOISE ASSEMBLY	AN/APG-68	✓	✓
691R750G01		5895	01-193-7344	INTERMEDIATE FREQUENCY ASSEMBLY	AN/APG-68	✓	
7276-1	585028	5996	01-464-4836	LNA	AN/APG-68		✓
750R450G04		5841	01-203-4624	TRANSMIT MICROWAVE ASSEMBLY	AN/APG-68	✓	
750R820		1270	01-169-6289	RECEIVER-GENERATOR, RADAR	AN/APG-68	✓	
750R820G01		1270	01-169-6289	RECEIVER-GENERATOR, RADAR	AN/APG-68	✓	
750R821G01	585260	1270	01-168-5002	STALO FREQUENCY SYNTHESIZER	AN/APG-68	✓	✓
750R824G01		1270	01-168-5004	FREQUENCY OSCILLATOR	AN/APG-68	✓	
756R222G01	585075	5998	01-195-8634	CONTROLLER ANALOG CCA	AN/APG-68	✓	✓
756R358G01		1270	01-213-3377	INTERFACE CONTROLLER	AN/APG-68	✓	
758R139G01	585050	1270	01-132-2440	PHASE SHIFT DRIVER	AN/APG-68	✓	✓
758R490G01	588395	5841	01-196-3703	GROUND DECK PULSER CCA	AN/APG-68		✓
758R862G01	588100	1270	01-223-5840	INTERMEDIATE FREQUENCY ASSEMBLY	AN/APG-68	✓	✓
762R615G01		5998	01-307-5241	CIRCUIT CARD ASSEMBLY	AN/APG-68	✓	
762R978	588385	5998	01-306-9224	PROTECTION AND CONTROL CCA	AN/APG-68	✓	✓
762R978G01	588385	5998	01-306-9224	PROTECTION AND CONTROL CCA	AN/APG-68	✓	✓
765R610G01		1270	01-413-5648	PROCESSOR SIGNAL	AN/APG-68	✓	
775178G01		1270	01-169-6289	RECEIVER-GENERATOR, RADAR	AN/APG-68	✓	
775R178G01		1270	01-418-1960	GENERATOR RECEIVER	AN/APG-68	✓	
783R086G01	585050	1270	01-132-2440	PHASE SHIFT DRIVER	AN/APG-68	✓	✓
785R017G01		5998	01-332-9651	CIRCUIT CARD ASSEMBLY	AN/APG-68	✓	
785R767G01		5998	01-423-6943	CIRCUIT CARD ASSEMBLY	AN/APG-68	✓	
785R789G01		5998	01-426-3528	ELECTRONIC COMPONENTS ASSY	AN/APG-68	✓	
785R953G01		5998	01-425-6022	CIRCUIT CARD ASSEMBLY/ NON-VOLATILE MEMORY	AN/APG-68	✓	
785R980G01		1270	01-492-6324	PROCESSOR, RADAR	AN/APG-68	✓	
792R028G01		*	*	CIRCUIT CARD ASSEMBLY	AN/APG-68	✓	
792R689G01		5998	01-465-7637	CIRCUIT CARD ASSEMBLY	AN/APG-68	✓	
810R794G01		5998	01-529-1748	COMPONENTS ASSY	AN/APG-68	✓	
817R226G01		5841	01-486-1338	RADAR RECEIVER	AN/APG-68	✓	
817R266G01		*	*	LOW NOISE ASSY	AN/APG-68	✓	
825R860		5841	01-525-1534	RADAR TRANSMITTER	AN/APG-68	✓	
825R860G01		5841	01-525-1534	RADAR TRANSMITTER	AN/APG-68	✓	

OEM P/N	USD P/N	FSC	NIIN	DESCRIPTION	SYSTEM	REPAIR	NEW BUILD
AF AVIONICS S/P IL		5985	01-294-9788	ANTENNA CONTROL	AN/APG-68	✓	
AM-7314/URN		5985	01-228-9402	AMPLIFIER-CONVERTER	AN/APG-68	✓	
AS-3820A/AR		5985	01-294-9788	ANTENNA CONTROL	AN/APG-68	✓	
AS-3820B/AR		5985	01-352-9699	ANTENNA CONTROL	AN/APG-68	✓	
ASC1561583		5985	01-228-9402	AMPLIFIER-CONVERTER	AN/APG-68	✓	
FS9179A		6625	01-124-0226	FREQUENCY MULTIPLIER	AN/APG-68	✓	
M00X221		6625	01-124-0226	FREQUENCY MULTIPLIER	AN/APG-68	✓	
M00X224		6625	01-124-0226	FREQUENCY MULTIPLIER	AN/APG-68	✓	
M00X224-A		6625	01-124-0226	FREQUENCY MULTIPLIER	AN/APG-68	✓	
M124		6130	01-439-0638	MLOW POWER RF LOW VOLTAGE POWER SUPPLY	AN/APG-68	✓	
SCD7288		5895	01-421-6495	NOISE LIMITER	AN/APG-68	✓	
VLX1720		5895	01-421-6495	NOISE LIMITER	AN/APG-68	✓	
16VE009002-6		1270	01-093-2256	RADAR TRANSMITTER	AN/APG-68, AN/APG-66	✓	
682R669G01		1270	01-093-2256	RADAR TRANSMITTER	AN/APG-68, AN/APG-66	✓	
822-0204-002		5826	01-387-0975	RADIO NAVIGATION RECEIVER	AN/APG-68, AN/ASN-163	✓	
R-2514A/U		5826	01-387-0975	RADIO NAVIGATION RECEIVER	AN/APG-68, AN/ASN-163	✓	
772R876G01		5998	01-327-2983	CIRCUIT CARD ASSEMBLY	AN/APG-68; AN/APG-66	✓	
781R749G01		5998	01-327-2983	CIRCUIT CARD ASSEMBLY	AN/APG-68; AN/APG-66	✓	
781R997G01		5998	01-327-2983	CIRCUIT CARD ASSEMBLY	AN/APG-68; AN/APG-66	✓	
785R104G01		5998	01-327-2983	CIRCUIT CARD ASSEMBLY	AN/APG-68; AN/APG-66	✓	
785R116G01		5998	01-327-2983	CIRCUIT CARD ASSEMBLY	AN/APG-68; AN/APG-66	✓	
792R08		5998	01-327-2983	CIRCUIT CARD ASSEMBLY	AN/APG-68; AN/APG-66	✓	
16VC006	475231	6615	01-071-4513	RATE GYROS	FLIGHT CONTROL SYSTEM		✓
67699-302	475231	6615	01-071-4513	RATE GYROS	FLIGHT CONTROL SYSTEM		✓
10055016-105		5998	01-083-8968	PITCH AXIS	HEAD UP DISPLAY SET	✓	
10055016-106		5998	01-084-1331	YAW AXIS	HEAD UP DISPLAY SET	✓	
10055016-108		5998	01-084-1331	YAW AXIS	HEAD UP DISPLAY SET	✓	
10055016-109		5998	01-083-8968	PITCH AXIS	HEAD UP DISPLAY SET	✓	
10055016-110		5998	01-084-1331	YAW AXIS	HEAD UP DISPLAY SET	✓	
10055022-103		5999	01-087-8648	POWER SUPPLY	HEAD UP DISPLAY SET	✓	
12-018-05	575500	6615	01-078-4943	RATE SENSOR UNIT	HEAD UP DISPLAY SET	✓	✓
16VE017005-5	575500	6615	01-078-4943	RATE SENSOR UNIT	HEAD UP DISPLAY SET	✓	✓
GG1500BA03	575500	6615	01-078-4943	RATE SENSOR UNIT	HEAD UP DISPLAY SET	✓	✓
10059851	446226	6615	01-071-6110	RATE INTEGRATING GYROS	HEADS UP DISPLAY RATE SENSOR	✓	✓
10059851	446226	6615	01-527-9183	RATE INTEGRATING GYROS	HEADS UP DISPLAY RATE SENSOR	✓	✓
10059849-101	475134	6615	01-071-4292	RATE GYROS	HEADS UP DISPLAY RATE SENSOR		✓
GG445D11	475134	6615	01-071-4292	RATE GYROS	HEADS UP DISPLAY RATE SENSOR		✓
16E1361-277		5945	01-171-7231	MATRIX ASSEMBLY	N/A	✓	
16E1361-279		1680	01-195-4710	MATRIX ASSEMBLY	N/A	✓	
785R01		5998	01-332-9651	CIRCUIT CARD ASSEMBLY	PROCESSOR, RADAR TARGET DATA	✓	
785R114G01		5998	01-332-9651	CIRCUIT CARD ASSEMBLY	PROCESSOR, RADAR TARGET DATA	✓	
785R161		5998	01-332-9651	CIRCUIT CARD ASSEMBLY	PROCESSOR, RADAR TARGET DATA	✓	
785R161G01		5998	01-332-9651	CIRCUIT CARD ASSEMBLY	PROCESSOR, RADAR TARGET DATA	✓	
78R114G01		5998	01-332-9651	CIRCUIT CARD ASSEMBLY	PROCESSOR, RADAR TARGET DATA	✓	
792R087G01		5998	01-332-9651	CIRCUIT CARD ASSEMBLY	PROCESSOR, RADAR TARGET DATA	✓	